

INSTRUCTIONS FOR:

Model No: AK45X.V2

BUCKET GREASER WITH FOLLOWER PLATE 12.5KG HEAVY-DUTY

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.



IMPORTANT. PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS AND CAUTIONS. USE THIS PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE, OR PERSONAL INJURY, AND WILL INVALIDATE THE WARRANTY. RETAIN THESE INSTRUCTIONS FOR FUTURE IISE

1. SAFETY INSTRUCTIONS

- ✓ Maintain the AK45X.V2 in good condition keeping it clean for the best and safest performance.
- ✓ Replace or repair damaged parts. Use recommended parts only. Unauthorised parts may be dangerous and will invalidate the warranty.
- ✓ Follow general working environment safety operating procedures at all times.
- ✓ Wear appropriate protective clothing.
- ✓ Use AK45X.V2 in an appropriate working area for its function. Keep area clean and tidy and free from unrelated materials and ensure there is adequate lighting.
- ✓ Maintain correct balance and footing. Ensure the floor is not slippery and wear non slip-shoes.
- ✓ Keep children and unauthorised persons away from the working area.
- ✓ Dispose of waste grease in accordance with local authority regulations.
- X DO NOT allow unauthorised persons to operate the gun.
- X DO NOT point gun at yourself or at other persons or animals.
- X DO NOT allow uncontrolled discharge of grease.
- X DO NOT use the AK45X.V2 for a task it is not designed to perform.
- √ When not in use store the gun in a safe, dry, childproof area.

2. DESCRIPTION

Zinc die-cast pump head with pressed steel pump and carry handle. Suitable for 12.5kg and some 20kg grease buckets. Supplied with follower plate to prevent cavitation and ensure smooth flow of grease. Suitable for bulk packing bushings and bearings where requirement is for grease volume and not grease pressure. Includes rigid extensions and 4-jaw coupler.

3. SPECIFICATIONS & ASSEMBLY


3.1. Specification.

3.2. Assembly.

- 3.2.1 Assemble pump (fig 1.1) through drum cover (2) securing the retention adaptor.
- 3.2.2 Assemble hose (4) to pump outlet after having removed plastic blank plug.
- 3.2.3 Take a 12.5kg (or 20kg) container of grease and ensuring there are no large pockets of air in the grease container, hold the container about 1" from the ground and allow the container to drop the effect of which will settle the content.
- 3.2.4 Remove lid from the container and push follower plate (3) into grease with the plastic stem uppermost until a small quantity of lubricant appears through the central aperture.
- 3.2.5 Install pre-assembled pump unit and drum cover onto grease container and secure with the 3 drum retaining wing screws.

4. OPERATING INSTRUCTIONS

- 4.1 Prime unit by operating handle slowly until lubricant emerges from end of 4-jaw hydraulic connector (fig.1.6) (approx. 20-25 operations).
- 4.2 When fully primed a slight resistance will be felt on the pump down stoke indicating the pump is ready for use (normal operating pressure is 200bar).
- 4.3 If priming problems are experienced, initial priming should be done with a heavy grade oil.



Caution: The 4-jaw hydraulic connector (6) is an integral part of the angle tube (5) nozzle end. If jaws need replacement care must be take when unscrewing end as jaws are tensioned with a strong spring.

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. **IMPORTANT:** No liability is accepted for incorrect use of product. **WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim. **INFORMATION:** Call us for a copy of our latest catalogue on 01284 757525 and leave your full name and address including your postcode.



Sole UK Distributor Sealey Group, Bury St. Edmunds, Suffolk. **a** 01284 757500



www.sealey.co.uk

≜ 01284 703534

sales@sealey.co.uk