

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.




IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS AND CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY INSTRUCTIONS

1.1. GENERAL SAFETY

- WARNING!** Ensure Health & Safety, local authority and general workshop practice regulations are adhered to when using this equipment.
- ✓ Familiarise yourself with the application, limitations and hazards of the cleaner.
- WARNING!** Disconnect the cleaner from the air supply before changing accessories, servicing or performing any maintenance.
- ✓ Maintain the cleaner in good condition (use an authorised service agent).
- ✓ Replace or repair damaged parts. Use *genuine parts only*. *Unauthorised parts may be dangerous and will invalidate the warranty.*
- ✓ Keep the work area clean, uncluttered and ensure that there is adequate lighting.
- ✓ Keep the cleaner clean for best and safest performance.
- ✓ Maintain correct balance and footing. Ensure that the floor is not slippery and wear non-slip shoes.
- ✓ Keep children and unauthorised persons away from the work area.
- WARNING!** Ensure that correct air pressure is maintained and not exceeded.
- ✓ Keep air hose away from heat, oil and sharp edges. Check air hose for wear before each use and ensure that all connections are secure.
- x **DO NOT** use the cleaner for any purpose other than that for which it is designed.
- x **DO NOT** operate the cleaner if any parts are damaged or missing as this may cause failure and/or personal injury.
- x **DO NOT** stand on the cleaner.
- x **DO NOT** adjust or tamper with the safety valve.
- x **DO NOT** move the cleaner by the hose, or yank the hose from the air supply.
- x **DO NOT** place attachments close to your face (especially eyes, ears, etc.) and do not point hose at other persons or animals.
- x **DO NOT** allow untrained persons to operate the cleaner.
- x **DO NOT** operate the cleaner when you are tired or under the influence of alcohol, drugs or intoxicating medication.
- x **DO NOT** leave the cleaner operating unattended.
- x **DO NOT** direct air from the air hose at yourself or others.
- ✓ When not in use disconnect from the air supply, vent reservoir and store in a safe, dry, childproof area.
- ✓ Dispose of waste fluid in accordance with local authority regulations.
- WARNING!** *DO NOT pollute the environment by allowing uncontrolled discharge of waste.*



2. INTRODUCTION AND ASSEMBLY

2.1. Introduction


Reduce the chances of brake dust getting airborne and help protect you and your workforce from the effects of brake dust inhalation. Air operated brake cleaner device can be used remotely from air supply and the recycling function prolongs the life of the brake cleaning fluid. Cranked neck makes this unit suitable for use under lift or next to ramps. Fitted with four large castor wheels, two braked, for workshop mobility. Suitable for use with Sealey Brake Cleaning Solvent or other proprietary brands. Supplied with cleaning brush.

2.2. Contents

- 2.2.1. Check the contents against the following list. If any items are damaged or missing contact your supplier immediately.
- Tank Assembly • Small Drain Pan • Large Drain Pan • Drain Pan Pipe • Brush and Hose • Drain Pan Mat

2.3. Assembly


- 2.3.1. Screw the small drain pan onto the threaded end of the drain pan pipe.
- 2.3.2. Insert other end of drain pan pipe (fig. 1.A) into the top tank fitting (fig. 1.D), as far as the spring ring (fig. 1.B). Tighten the pipe clamp screw (fig. 1.C).



3. AIR SUPPLY

The recommended hook-up is shown below.

- 3.1. Ensure the air valve is in the "Off" position before connecting to the air supply.
- WARNING!** Ensure the air supply is clean and does not exceed pressures specified in these Instructions. Too high an air pressure and/or unclean air will shorten the drainer life due to excessive wear, and may be dangerous, causing damage and/or personal injury.
- 3.2. Drain the compressor air tank daily and clean the air inlet filter weekly.
- 3.3. Line pressure should be increased to compensate for unusually long air hoses (over 8 metres). The minimum hose diameter should be 10mm I.D. and fittings must have the same inside dimensions.
- 3.4. Keep hoses away from heat, oil and sharp edges. Check hoses for wear and make certain that all connections are secure.



4. OPERATION

☐ **WARNING!** Ensure that you read, understand and apply the safety instructions in Section 1.

4.1. Filling.

- 4.1.1. Open the pressure relief valve to ensure that there is no pressure in the lower tank (there is a valve between the upper and lower tanks which is closed when the lower tank is pressurized and open when it is not).
- 4.1.2. Fill the lower tank with Brake Cleaning Solvent by pouring it into the drain pan, from where it will run through the upper tank into the lower tank. Check solvent level in sight tube. Approximate fill volume is 15 litres.

4.2. Operation.

- 4.2.1. Position the cleaner pan (large or small to suit application) under the brake assembly and tighten the pipe clamp screw.
- 4.2.2. Connect the brush hose to either the direct or impulse outlet, as required.
- 4.2.3. Check that the inlet valve and relief valves are closed and then connect an air line to the air inlet. Supply pressure should not exceed 90psi.
- 4.2.4. Turn on the air supply, open the inlet valve and adjust the pressure regulator to give a suitable solvent flow from the brush (typically 1 to 2 bar). DO NOT exceed 90psi (6 bar).
- 4.2.5. Carry out the cleaning operation. The dirty fluid will flow from the pan into the upper tank. The valve between the tanks will prevent the fluid from entering the lower tank until the lower tank pressure is vented.
- 4.2.6. When cleaning is finished, close the air inlet valve and open the relief valve. The used fluid in the upper tank will now flow into the lower tank, passing through the upper tank filter.

Note: If necessary the unit can be operated disconnected from the air supply - once the lower tank has been pressurized close the inlet valve and disconnect the air supply. The cleaner will now operate as normal until the pressure in the lower tank falls too low to provide an adequate solvent flow.

4.3. Emptying.


☐ **WARNING!** Ensure that the cleaner is disconnected from the air supply and that the relief valve is open.

- 4.3.1. Place a suitable container under the lower tank and then remove the drain plug.
- 4.3.2. When the tank is drained replace the drain plug.

☐ **IMPORTANT!** Dispose of waste solvent in accordance with local authority regulations.

4.4. Filter.

- Regularly remove and clean the upper tank filter.
- 4.4.1. Remove drain pipe from upper tank cover.
- 4.4.2. Open the four cover retaining clips and remove the cover.
- 4.4.3. Lift out the filter and clean with soapy water. Thoroughly rinse and dry.
- 4.4.4. Install the cleaned dry filter, replace and clip down the cover and refit the drain pipe.



Parts support is available for this product. To obtain a parts listing and/or diagram, please log on to www.sealey.co.uk, email sales@sealey.co.uk or phone 01284 757500.

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.



SEALEY Professional
TOOLS
Auto Service Line

Sole UK Distributor, Sealey Group,
Kempson Way, Suffolk Business Park,
Bury St. Edmunds, Suffolk,
IP32 7AR

☎ 01284 757500

☎ 01284 703534



www.sealey.co.uk



sales@sealey.co.uk