Hobby Knife Instructions
Model No: AK2410

Blade projection function

A With index finger and thumb grip the rubber sleeve and with your other hand rotate the back end of the knife clockwise to extend the blade. Rotate anti-clockwise to retract. Ensure the blade is fully retracted.



Spare blade storage

B Press down on the pocket clip and pull back to expose blade storage compartment. Store blades with sharp point innermost.

Cover removal

C With index finger and thumb grasp the chrome sleeve and rotate clockwise whilst holding the back end of the knife securely with your other hand.



Blade removal (with thin nosed pliers)

D Clamp the blade while rotating the knurled clutch ring clockwise to loosen. Pull to remove blade. Caution! Be aware the blade is very sharp, worn or new.

Blade and cover installation

E Align the blade back edge with arrow and tighten the knurled clutch sleeve by turning anti clockwise. Align arrows on cover sleeve and knife body. Slide on front cover and tighten chrome collar by rotating anti-clockwise.

Hobby Knife Instructions
Model No: AK2410

Blade projection function

A With index finger and thumb grip the rubber sleeve and with your other hand rotate the back end of the knife clockwise to extend the blade. Rotate anti-clockwise to retract. Ensure the blade is fully retracted.



Spare blade storage

B Press down on the pocket clip and pull back to expose blade storage compartment. Store blades with sharp point innermost.

Cover removal

C With index finger and thumb grasp the chrome sleeve and rotate clockwise whilst holding the back end of the knife securely with your other hand.



Blade removal (with thin nosed pliers)

D Clamp the blade while rotating the knurled clutch ring clockwise to loosen. Pull to remove blade. Caution! Be aware the blade is very sharp, worn or new.

Blade and cover installation

E Align the blade back edge with arrow and tighten the knurled clutch sleeve by turning anti clockwise. Align arrows on cover sleeve and knife body. Slide on front cover and tighten chrome collar by rotating anti-clockwise.



Hobby Knife Instructions
Model No: AK2410

Blade projection function

A With index finger and thumb grip the rubber sleeve and with your other hand rotate the back end of the knife clockwise to extend the blade. Rotate anti-clockwise to retract. Ensure the blade is fully retracted.



Spare blade storage

B Press down on the pocket clip and pull back to expose blade storage compartment. Store blades with sharp point innermost.

Cover removal

C With index finger and thumb grasp the chrome sleeve and rotate clockwise whilst holding the back end of the knife securely with your other hand.



Blade removal (with thin nosed pliers)

D Clamp the blade while rotating the knurled clutch ring clockwise to loosen. Pull to remove blade. Caution! Be aware the blade is very sharp, worn or new.

Blade and cover installation

E Align the blade back edge with arrow and tighten the knurled clutch sleeve by turning anti clockwise. Align arrows on cover sleeve and knife body. Slide on front cover and tighten chrome collar by rotating anti-clockwise.



Hobby Knife Instructions
Model No: AK2410

Blade projection function

A With index finger and thumb grip the rubber sleeve and with your other hand rotate the back end of the knife clockwise to extend the blade. Rotate anti-clockwise to retract. Ensure the blade is fully retracted.



Spare blade storage

B Press down on the pocket clip and pull back to expose blade storage compartment. Store blades with sharp point innermost.

Cover removal

C With index finger and thumb grasp the chrome sleeve and rotate clockwise whilst holding the back end of the knife securely with your other hand.



Blade removal (with thin nosed pliers)

D Clamp the blade while rotating the knurled clutch ring clockwise to loosen. Pull to remove blade. Caution! Be aware the blade is very sharp, worn or new.

Blade and cover installation

E Align the blade back edge with arrow and tighten the knurled clutch sleeve by turning anti clockwise. Align arrows on cover sleeve and knife body. Slide on front cover and tighten chrome collar by rotating anti-clockwise.

Hobby Knife Instructions
Model No: AK2410

Blade projection function

A With index finger and thumb grip the rubber sleeve and with your other hand rotate the back end of the knife clockwise to extend the blade. Rotate anti-clockwise to retract. Ensure the blade is fully retracted.



Spare blade storage

B Press down on the pocket clip and pull back to expose blade storage compartment. Store blades with sharp point innermost.

Cover removal

C With index finger and thumb grasp the chrome sleeve and rotate clockwise whilst holding the back end of the knife securely with your other hand.



Blade removal (with thin nosed pliers)

D Clamp the blade while rotating the knurled clutch ring clockwise to loosen. Pull to remove blade. Caution! Be aware the blade is very sharp, worn or new.

Blade and cover installation

E Align the blade back edge with arrow and tighten the knurled clutch sleeve by turning anti clockwise. Align arrows on cover sleeve and knife body. Slide on front cover and tighten chrome collar by rotating anti-clockwise.



Hobby Knife Instructions
Model No: AK2410

Blade projection function

A With index finger and thumb grip the rubber sleeve and with your other hand rotate the back end of the knife clockwise to extend the blade. Rotate anti-clockwise to retract. Ensure the blade is fully retracted.



Spare blade storage

B Press down on the pocket clip and pull back to expose blade storage compartment. Store blades with sharp point innermost.



Cover removal

C With index finger and thumb grasp the chrome sleeve and rotate clockwise whilst holding the back end of the knife securely with your other hand.



Blade removal (with thin nosed pliers)

D Clamp the blade while rotating the knurled clutch ring clockwise to loosen. Pull to remove blade. Caution! Be aware the blade is very sharp, worn or new.

Blade and cover installation

E Align the blade back edge with arrow and tighten the knurled clutch sleeve by turning anti clockwise. Align arrows on cover sleeve and knife body. Slide on front cover and tighten chrome collar by rotating anti-clockwise.