



instructions fo HEATING TORCH INSTRUCTIONS FOR: **BUTANE MICRO** MODEL No: AK4041

Thank you for purchasing a Sealey Product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.



IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS AND CAUTIONS. USE THIS PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE

SAFETY INSTRUCTIONS

- WARNING! Ensure Health & Safety, local authority, and general workshop practice regulations are adhered to when using this equipment.
- П WARNING! Always wear approved eye / face protection when operating the torch.
- WARNING! Butane gas is extremely flammable, handle with care.
- WARNING! Always point the torch away from the eyes and body when igniting and during operation.
- \Box WARNING! Ensure the flame is completely extinguished after use.
- WARNING! Only use in a well ventilated area.
- DO NOT use the torch in an area where paint fumes, solvents or other flammable solids, liquids or gases pose a potential X hazard. Keep flammable material away from the torch when operating.
- DO NOT operate the torch when you are tired or under the influence of alcohol, drugs or intoxicating medication. х
- X DO NOT hold any workpiece by hand.
- х DO NOT touch the workpiece close to the heated area as it will be very hot. Allow to cool.
- DO NOT operate the torch if it is damaged as this may cause failure and/or possible personal injury. X
- X DO NOT touch the top of the torch during or immediately after use, as it will be very hot. Allow to cool.
- X DO NOT leave the torch operating unattended.
- X DO NOT use this torch continuously for longer than 5 minutes.
- х DO NOT allow children to operate the torch.
- After use, allow the torch to cool before storing it.
- When not in use, store away from direct sunlight in a safe, dry, childproof location.

2. INTRODUCTION

Stylish design with piezo ignition. Produces a flame of approximately 1300°C. Powered by Butane (lighter fluid) and when full can produce a flame for up to 30 minutes (not to be used continuously for more than five minutes). Suitable for use in extreme weather conditions. Ideal for soft soldering, camping, household repairs and a variety of general purpose uses. Supplied with key chain.


3. OPERATION

To fill, turn the torch so that the filling valve (fig.1) is facing upwards. Press nozzle of Butane fuel re-filler can into filling valve and fill torch until at least 3/4 full. Allow fuel to warm for 5 minutes before use.

TO USE.

- 3.2. Flip up the Flame Nozzle Cover (fig.1A) and slowly push down on the Ignition Button (fig.1B) and keep holding it down.
- 3.3. To adjust flame, use the Flame Adjuster in the base (see fig.1C for direction of adjustment).
 - Note that if the adjuster is left set too high or too low, the torch may not re-light next time, so re-set after use.
- To turn off, release the Ignition Button. Close the Flame Nozzle Cover to protect the nozzle. Note that the cover is NOT designed to turn off the flame, do not close it when the flame is still lit

DO NOT use continuously for more than 5 minutes. Allow to cool for a minute before re-lighting.



NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. IMPORTANT: No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.





Sole UK Distributor, Sealey Group, Kempson Way, Suffolk Business Park, Bury St. Edmunds, Suffolk, IP32 7AR





sales@sealey.co.uk