

INSTRUCTIONS FOR:

FLOOR SWEEPER 800MM

MODEL No. FSW80

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.


1. SAFETY INSTRUCTIONS

- \checkmark Ensure that the sweeper is only used on hard/dry surfaces.
- ✓ Ensure that the dirt collection hopper is present and properly seated before commencing sweeping.
- ✓ The sweeper is for indoor use only.
- X Do not leave the sweeper unattended, where it could become a hazard to other people or traffic in the sweeping area. For example, in a warehouse situation.
- X Do not allow anyone to ride on the sweeper.
- X Do not use the sweeper for any purpose other than that for which it was designed.
- X Do not use the sweeper to clear up hazardous materials or any material that may attack the plastic chassis of the sweeper.
- **x** Do not use the sweeper on wet surfaces.

2. INTRODUCTION

Suitable for maintaining any hard floor and ideal for removing dirt, dust and debris from large surface areas. Features 4-brush system with two side brushes and two further brushes set underneath the unit to easily lift debris into the hopper. Fitted with tubular handle and adjustable castor wheel that raises the sweeper 20mm enabling larger pieces of debris to be swept up.

Model No.	FSW80
Operating Width	800mm
Hopper capacity	40ltr



3. ASSEMBLY & USE

- **3.1 Lower Handle:** Take the lower handle tube and place the slots in the flattened ends over the threaded spigots on the handle brackets, see fig.1B. Ensure that the open slots at each end of the lower handle are engaged with the plain spigot on the mounting brackets. Retain the handle in place by screwing a black plastic knob onto each threaded spigot.
- **3.2 Upper Handle:** The upper handle has three alternative mounting holes in the flattened portions of the handle. Align the chosen mounting holes with the holes in the upper part of the lower handle and insert the supplied coach bolts through both frames and retain with the black plastic knobs supplied as shown in fig.1A.
- **3.3 Handle stowage:** The handle can be folded down for storage purposes. Loosen the lower mounting knobs and pull the handle upwards to disengage the slotted ends from the plain spigots on the mounting brackets. Hinge the handle forwards and allow it to rest on the body of the sweeper.
- **3.4 Circular brushes:** Attach each brush to its hub using the 6 screws provided (3 for each brush). Ensure each brush is correctly seated before tightening.
- **3.5 Use:** Ensure the handle height is correctly adjusted for the convenience of the operative. Make sure that the handle fixings are tight and the dirt collection hopper is properly seated within the main body of the sweeper. Work methodically up and down the area to be swept, ensuring that each 'pass' overlaps the previous one. To ensure the efficiency of the brushes, push the sweeper at a good, even pace. To capture larger pieces of debris the basic clearance of the sweeper can be raised a further 20mm by rotating the height adjuster seen in fig.1 clockwise. Check the hopper regularly by lifting it out. Empty it if required. Place it back into the sweeper as shown in fig.2. Periodically, clean the exterior of the sweeper with a damp cloth.

fig.2

01284 757500

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. IMPORTANT: No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim. INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.



Sole UK Distributor, Sealey Group, Kempson Way, Suffolk Business Park, Bury St. Edmunds, Suffolk, IP32 7AR

FSW80 Issue: 1 - 11/11/11

www.sealey.co.uk

🗈 01284 703534 🛛 📷 sales@sealey.co.uk

F

Original Language Version



PARTS FOR: FLOOR SWEEPER 800mm MODEL: FSW80

42 - 41 - 41 - 41 - 41 - 41 - 41 - 41 -	$ \begin{array}{c} & & & & & & \\ & & & & & & \\ & & & & & $
ITEM PART NO DESCRIPTION 1 FSW80.01 LOCK NUT (M6) 2 FSW80.02 WASHER 3 FSW80.03 SCREW (ST3.9x16) 4 FSW80.04 ROUND BRUSH 5 FSW80.05 PULLEY 6 FSW80.06 SCREW (3.9x18) 7 FSW80.07 BRUSH SUPPORT 8 FSW80.08 BEARING (608) 9 FSW80.10 SPINDLE FOR ROUND B 11 FSW80.11 BEARING COVER 12 FSW80.12 SCREW (ST3.9x12) 13 FSW80.12 SCREW (ST3.9x12) 13 FSW80.13 SCREW (ST3.9x25) 16 FSW80.14 ROLLER SUPPORT (RIC 17 FSW80.15 SCREW (ST3.9x25) 16 FSW80.17 PUNCH BEARING 17 FSW80.18 BELT PULLEY 19 FSW80.20 RUBBER BELT (6x525) 21 FSW80.21 WHEEL 23 FSW80.22 WHEEL 23 <	 37 FSW80.37 BODY 38 FSW80.38 BOLT (6x50) 39 FSW80.39 HEIGHT ADJUSTABLE SWITCH 40 FSW80.40 COLLECTION TRAY (UPPER) 41 FSW80.41 COLLECTION TRAY (LOWER)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. **IMPORTANT:** No liability is accepted for incorrect use of product. **WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.

U)

	POWER PRODUCTS	Sole UK Distributor, Sealey Group, Kempson Way,	01284 757500	Web	www.sealey.co.uk
JL V	PRODUCTS	Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR	01284 703534	email	sales@sealey.co.uk