



PRODUCTS PRODUCTS DUMMY WIRELESS BELL BOX ALARM Model No. 67

INSTALLATION AND OPERATING INSTRUCTIONS

Keep this manual safe for reference and future maintenance

1. Introduction

The Dummy Wireless Bell Box Alarm:

- is designed to be fitted to the front of the property in a highly visible position, providing a permanent visual deterrent to intruders.
- has flashing lights to indicate when it's active. It is impossible to differentiate it from the real one.
- has a typical battery life of 1.5 years or more before they need changing.

2. Installation

- Remove the bell box cover by unscrewing the single screw located on the lid.
- Insert 2 x fresh alkaline 'AA' cells, noting their polarity.
- -The dummy bell box alarm is now active and the lights will flash.
- -The bell box is now ready for mounting. Please choose the best location (highly visible position) for mounting. Do not replace the cover vet.
- Using the large screws and wall plugs provided, mount on the desired wall through the mounting holes.
- Fix the bell box cover with the securing screw.

The product may be cleaned with a soft damp cloth and then wiped dry. Do not use abrasive, solvent based or aerosol cleaners as this may damage and/or discolour the product. Do not allow water to enter or attempt to clean inside the unit.

4. Batteries

Do not allow the batteries to corrode or leak as this may cause permanent damage to the product. Take care to insert the batteries with the correct polarity as shown inside the battery compartment. Do not mix new and old batteries or different types of batteries. Do not use rechargeable batteries. At the end of their useful life the batteries should be disposed of via a suitable recycling centre. Do not dispose of with your normal household waste. DO NOT BURN.

5. Alarm System Limitations

Even the most advanced alarm systems cannot guarantee 100% protection against burglary or environmental problems. All alarm systems are subject to possible compromise or failure-to-warn for a variety of reasons.



Environmental Protection.

Recycle unwanted materials instead of disposing of them as waste.

All tools, accessories and packaging should be sorted, taken to a recycle centre and disposed of in a manner which is compatible with the environment.



WEEE Regulations.

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment. When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.

Remove batteries from units when they are exhausted.

Under the Waste Batteries and Accumulators Regulations 2009, Jack Sealey Ltd are required to inform potential purchasers of products containing batteries (as defined within these regulations), that they are registered with Valpak's registered compliance scheme. Jack Sealey Ltd's Batteries Producer Registration Number (BPRN) is BPRN00705.

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice IMPORTANT: No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.









01284 703534 email sales@sealey.co.uk