

INSTRUCTIONS FOR:

## **TOWING MIRROR EXTENSION**

MODEL No: TB63

Thank you for purchasing a Sealey Product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.



IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS AND CAUTIONS. USE THIS PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.


## 1. SAFETY INSTRUCTIONS

- ✓ Familiarise yourself with this products application and limitations, as well as any specific potential hazards peculiar to the mirror.
- ✓ Always check the condition and security of the mirror before every journey, if any part is damaged or missing, DO NOT use.
- ✓ Replace or repair damaged parts. Use recommended parts only. Non authorised parts may be dangerous and will invalidate the warranty.
- **DO NOT** use the mirror for any purpose other than for which it is designed.
- X DO NOT use the mirror if any parts are missing or damaged as this may cause failure.
- WARNING: The warnings, cautions and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood that common sense and caution are factors which cannot be built into this product, but must be applied by the operator.

## 2. ASSEMBLY & OPERATION

- 2.1. Fit the tubular strap retaining clip and the L-shaped mirror clip to the rubber strap as shown in fig.1, ensure the ribs are on the inside. Ensure the small rubber protective feet are fitted to the ends of the mirror bracket clamp screws shown in fig.2.
- 2.2. Slide one mirror clamp onto the mirror bar, so the clamps will slide between the vehicle mirror and casing. Then slide on the tubular strap retaining clip, ensuring the ribbed side of the rubber strap is on the inside.
  - Fit the second mirror clamp bracket. The correct arrangement is shown in fig.2.
- 2.3. Offer the towing mirror to the vehicle mirror and fit the mirror clamp brackets, inserting the ends between the mirror and the casing. See fig.3 for correct positioning.
- **2.4.** Pass the rubber strap behind the body of the vehicle mirror (fig.5) and position the end of the L-shaped bracket between the mirror and the mirror casing, as shown in fig.4.

If the rubber straps do not have enough tension to provide a secure fixing remove the L-shaped bracket and adjust the straps. Keep adjusting and reattaching until the mirror is secure.



Note: Do not over tighten as this could damage your mirror casing.

2.6. When the mirror is fitted as in fig.5, check the overall security of the mirror. Adjust the mirror head for optimum rear view.











NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.



Sole UK Distributor, Sealey Group, Kempson Way, Suffolk Business Park, Bury St. Edmunds, Suffolk, IP32 7AR





Original Language Version