

# SEALEY POWER PRODUCTS

INSTRUCTIONS FOR:  
**WHEEL DOLLY SET 680KG CAPACITY**  
**MODEL No: WS681**

Your new Wheel Dollies are produced and manufactured to a high standard of dependability and will, if used according to these instructions and properly maintained, give you years of trouble free performance.

**IMPORTANT: READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS AND CAUTIONS. USE THESE DOLLIES CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH THEY ARE INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. RETAIN THESE INSTRUCTIONS FOR FUTURE USE.**

## 1. SAFETY PRECAUTIONS

- ❑ **WARNING!** Ensure Health & Safety, local authority, and general workshop practice regulations are adhered to when using this equipment.
- ✓ Familiarise yourself with this product's application and limitations, as well as the specific warnings below relating to their use.
- ✓ Ensure the Wheel Dollies are in sound condition and good working order. Take action for immediate repair or replacement of damaged parts.
- ✓ Use genuine parts only. The use of improper parts may be dangerous and will invalidate the warranty.
- ✓ Wheel Dollies should only be used in suitable, well lit areas.
- ✓ **Wheel Dollies must be used in pairs at either the front or rear of the vehicle.**  
They must never be used diagonally.
- ✓ Keep general area clean and tidy and free from obstructions.
- ✓ Use Wheel Dollies on level and solid ground, preferably concrete.
- ✓ Maintain the Wheel Dollies in good condition.
- ✓ Ensure there are no passengers in the vehicle.
- ✓ Ensure the Wheel Dollies are free to move and that there are no obstructions in the area of use.
- ✓ When not in use store Wheel Dollies in a safe, dry, childproof area.
- x **DO NOT start or drive the vehicle whilst it is raised on wheel dollies.**
- x **DO NOT** use the Wheel Dollies for purposes other than that for which they are intended.
- x **DO NOT** allow untrained persons to operate the Wheel Dollies.
- x **DO NOT** leave the vehicle unattended whilst it is raised on the Wheel Dollies.
- x **DO NOT** operate the Wheel Dollies when you are tired or under the influence of alcohol, drugs or intoxicating medication.
- x **DO NOT** get the Wheel Dollies wet or use in damp or wet locations or areas where there is condensation.
- x **DO NOT** exceed the rated capacity of the Wheel Dollies. Remember that the front of a vehicle is usually heavier than the rear.
- x **DO NOT** use the Wheel Dollies to support a vehicle in order to do work underneath it.
- ✓ Maintain correct balance and footing when moving vehicle. Ensure the floor is not slippery and wear non-slip shoes.
- ✓ Ensure all non-essential persons keep a safe distance whilst the Wheel Dollies are in use.
- IMPORTANT** - We recommend that at least 2 persons are involved in manoeuvring the vehicle when supported on wheel dollies. The vehicle's weight provides a large amount of inertia which has to be overcome to get the vehicle moving and more importantly, stopped.
- ❑ **WARNING!** The warnings, cautions and instructions covered in this manual cannot cover all possible conditions and situations that may occur. It must be understood that common sense and caution are factors which cannot be built into this product, but must be applied by the operator.



## 2. INTRODUCTION & SPECIFICATION

Heavy-duty steel plate with rust resistant finish. Fitted with four Ø 75mm metal castors with two lockable castors. Each dolly features a side handle for easy carrying. Can handle up to 250mm profiles. Suitable for bodyshops, workshops and car parks.

Lifting capacity per Dolly: . . . . 680kg      Maximum Tyre Profile: . . 250mm      Weight (Each): . . . . . 7.6kg  
 Wheel Ø: . . . . . Ø75mm

## 3. MAINTENANCE

- 3.1. Before each use check for any visible damage. If any suspect item is found remove dolly from service and take necessary action to remedy the problem.  
**DO NOT** use the dolly if believed to have been subjected to abnormal load or shock load.
- 3.2. Keep the dolly clean and periodically lubricate the wheels and castor bearings.

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.  
**IMPORTANT:** No liability is accepted for incorrect use of this product.  
**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.  
**INFORMATION:** For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode. **CE**

**SEALEY POWER PRODUCTS** Sole UK Distributor, Sealey Group, Kempson Way, Suffolk Business Park, Bury St. Edmunds, Suffolk, IP32 7AR

01284 757500      www.sealey.co.uk  
 01284 703534      sales@sealey.co.uk